

Table of Contents

REF: Tools - 128	3
Temporary Fuel Line for Testing Purposes	3

[Go To Technical Menu](#)

REF: Tools - 128

Temporary Fuel Line for Testing Purposes

If you've got your gas tank off but still want to test run your engine, run a temporary line to the carb from a test reservoir mounted higher than the carb to let gravity feed the carb.



This is an oil / fuel mixing syringe for 2 cycle engines that can be purchased for under \$5 at most automotive departments and parts stores. ¹⁾

You'll need a 1/4" hose clamp and app. 3 feet 1/4" fuel line. Drill a small hole in both the top and bottom flange of the mixer to prevent vacuum / suction problems. ²⁾

Press one end of the fuel line onto the fuel mixer, tighten the hose clamp around it and the other end to your carb inlet. ³⁾

Fill the mixer with gas, tap the line to get the air bubbles out, insert the plunger, and hang the round end over the front brake lever. Works like a charm, no mess, and you can run the engine for several minutes while freeing up one of your hands. ⁴⁾



Go To Technical Menu

1) , 2) , 3) , 4)

photo by Stupit of the XLFORUM

<https://www.xlforum.net/forum/sportster-motorcycle-forum/sportster-motorcycle-era-specific-and-model-specific/ironhead-sportster-motorcycle-talk-1957-1985/63858-special-tools/page5?t=395586&page=5>

From:

<http://www.sportsterpedia.com/> - **Sportsterpedia**

Permanent link:

<http://www.sportsterpedia.com/doku.php/techtalk:ref:tools128>

Last update: **2024/01/24 02:46**

