



# INSTRUCTIONS

-J00286

REV. 1-1-92

Kit Number 56075-91

## HANDLEBAR SWITCH KIT

### General

This kit is designed for installation on 1986 - 1991 XLH model vehicles.

This kit contains the following components:

QTY	DESCRIPTION
1	Handlebar switch, left
1	Handlebar switch, right
2	Cable tie
1	Connector
4	Tab, commoning (2 hole)
1	Tab, commoning (3 hole)
2	Bushing, right angle

#### NOTE

*Instructions for installing this kit are also included in the instructions for XLH 883 Sportster Buckhorn Handlebar Kit, Part No. 56078-92. If you are installing this kit with Buckhorn Handlebar Kit, you may use Buckhorn Handlebar Kit instruction sheet for wiring installation instructions.*

### Installation

1. Remove headlamp from headlamp housing following instructions in appropriate Service Manual.
2. Remove angle bushings that clamp switches' wiring harnesses to headlamp housing.
3. Install new switch wires through headlamp housing.
4. Use the old switch wires as a guide to correctly install the new switch wires. Match the color codes of the switch wires. Disconnect the old wires, one at a time, and replace each with the new, correctly color-coded wire. Do one at a time to avoid confusion. Replace connectors with new ones.
5. Remove the old switch wires from headlamp housing. Install new angle bushings in headlamp housing.
6. Install headlamp cover and headlamp following instructions in appropriate Service Manual.