



INSTRUCTIONS

-J00301

REV. 10-1-87

Kit Number 58007-86

WINDSHIELD MOUNTING KIT

General

This kit is designed for use when installing Windshield Kit Part No. 58001-71D onto 1986 FXR, 1983 and later XL, 1985 XLX and 1986 and later XLH model vehicles.

The following parts are included in the kit:

QTY	DESCRIPTION
2	Screw, sockethead 3/8 - 24 x 2 in.
2	Bolt, 5/16 - 24 x 3/4 in.
2	Washer, 3/8 in. flat (chrome)
2	Washer, 5/16 in. flat
2	Nuts, 5/16 - 24
1	Bracket, windshield mounting

Installation

1. Remove two (2) lower fork bracket pinch bolts.
2. Using new sockethead screws and chrome washers from kit, attach windshield mounting bracket to lower fork bracket so 90° bends in bracket point towards rear of vehicle. Torque sockethead screws to 30-35 ft-lbs.

3. Refer to Windshield Kit Instruction Sheet for windshield installation procedures.

NOTE

Use 5/16 - 24 x 3/4 in. bolts, 5/16 in. flat washer and 5/16 - 24 nuts from this kit through bottom hole in left and right fork brackets from Windshield Kit to attach to mounting bracket from this kit.

NOTE

Some models come equipped with directionals mounted to holes in top fork bracket that are needed to install windshield. To remove directionals first remove headlight from mounting bracket. Disconnect socket/pin connector housing located in the back of the headlight housing. Follow wires from directionals to socket connector housing (mark position of wires in housing to ensure correct replacement position). Remove directional wires from housing with socket connector removal tool. Remove directionals by unscrewing entire assembly. Position top hole in fork bracket from windshield kit over directional mounting hole. Assemble directional in reverse order of disassembly so directional mounting stud goes through top hole in fork bracket.