



INSTRUCTIONS

-J00459

REV. 3-1-86

*Kit Numbers 71563-82A, 71564-82A, 71567-82, 71568-82A, 71594-86,
and 71595-86*

SWITCH HOUSING

General

These kits are designed for use on all vehicles 1982 and later.

Installation

When installing one of these kits on 1985 or earlier models, the corresponding housing that came as original equipment will have tabs and recesses in various locations. These tabs were meant to fit into recesses in opposite housing half.

New housings are made without these tabs and recesses.

To fit new and old housing halves together, file or grind off the tabs. Carefully check fitment of housings. For switch installation, follow procedure outlined in applicable Service Manual.



INSTRUCTIONS

-J00459

REV. 3-1-86

*Kit Numbers 71563-82A, 71564-82A, 71567-82, 71568-82A, 71594-86,
and 71595-86*

SWITCH HOUSING

General

These kits are designed for use on all vehicles 1982 and later.

Installation

When installing one of these kits on 1985 or earlier models, the corresponding housing that came as original equipment will have tabs and recesses in various locations. These tabs were meant to fit into recesses in opposite housing half.

New housings are made without these tabs and recesses.

To fit new and old housing halves together, file or grind off the tabs. Carefully check fitment of housings. For switch installation, follow procedure outlined in applicable Service Manual.

