



# INSTRUCTIONS

-J00622

REV. 9-1-86

*Kit Number 54500-67T*

## SHOCK ABSORBER

During installation, make sure open end of cam support slot at bottom of shock absorber is facing toward motorcycle.



# INSTRUCTIONS

-J00622

REV. 9-1-86

*Kit Number 54500-67T*

## SHOCK ABSORBER

During installation, make sure open end of cam support slot at bottom of shock absorber is facing toward motorcycle.



# INSTRUCTIONS

-J00622

REV. 9-1-86

*Kit Number 54500-67T*

## SHOCK ABSORBER

During installation, make sure open end of cam support slot at bottom of shock absorber is facing toward motorcycle.



# INSTRUCTIONS

-J00622

REV. 9-1-86

*Kit Number 54500-67T*

## SHOCK ABSORBER

During installation, make sure open end of cam support slot at bottom of shock absorber is facing toward motorcycle.