Cruise Control Set/Resume Switch

Here is another way to check the operation of the Set/Resume switch. With the ignition on and the switch held in the Set position, measure voltage on the set wire at the connector to the cruise module (with the module connected) you should see battery voltage. Then leave the switch in the Set position and check for voltage on the Resume wire at the connector to the cruise module, there should not be voltage. Then check the wires again holding the switch in the Resume position. There should be battery voltage on the Resume wire and not on the Set wire. If you have voltage on both wires when the switch is held in either position then the wires are shorted together or you have a faulty Set/Resume switch.